

Using the PIP window

During a videoconference, the remote site is displayed in your main video window. You can open a PIP (Picture-In-Picture) window to display the local view (the image you are sending to the remote site).



To open the PIP, click the **PIP** button on the AppsView toolbar.

To close the PIP, click the **PIP** button again.

Adjusting the color of the video image

To learn how to access the System Tools button, see "Displaying AppsView toolbars" on page 16.



1 Click the **System Tools** button to display the System Tools toolbar.



2 On the System Tools toolbar, click the **Control Panel** button. The Control Panel window opens.

3 Select the **Video** tab.



4 Use the slider bars to adjust the color, hue, contrast, and brightness.